

Diesel Power Products
325 N. Oregon Ave.
Pasco, WA 99301
(509) 547-7029

Turbo Air Guide (TAG) installation:

1. Inspect the edges of the Turbo Air Guide for burrs and loose pieces. Even though these parts are cleaned and deburred before shipping you still want to make sure there are no loose pieces which could come loose and be drawn into the turbo. Be sure to wear gloves to protect your hands as some edges may be sharp.
2. Remove the air inlet hose from the air filter housing to the intermediate support.
3. Remove the two 8mm bolts from the intermediate hose support and the small green tube from the tapered hose going to the turbo intake. Loosen the clamps on both ends of the tapered hose and remove it from the turbo inlet.
4. Install the Turbo Air Guide into the turbo inlet housing. It may be necessary to apply some pressure to the TAG to get it seated with the flange touching the face of the turbo inlet on 1999-2003 Fords. The TAG will not be a tight fit in 1995-1999 early turbo housings and care should be taken to ensure the TAG is properly located with the hose in place. Once the TAG is seated, reinstall the hoses holding them securely against the turbo housing and clamp securely.



The TAG is so new, no claims are made for performance or mileage increases as results will vary with modifications and configuration of different vehicles. No warranty is given or implied and any damages resulting from the use of this product are strictly the responsibility of the user.