Dfuser Fuel Filter Drain Valve O-Rings

User Guide

This kit includes two new O-Rings required to fix the fuel leak typically found under you truck due to bad O-Rings. Ford ™ only offers the whole assembly for replacement.

Installation Instructions

Start by opening the valve and draining the water and fuel. Remove the attached hose to the drain assembly. Using a Torx #20, remove 4 bolts holding the valve to the fuel filter assembly. Place on a clean bench, clean drain valve, remove and discard old O-rings, and install new rings supplied. Use some white lithium grease to hold O-Rings to drain valve. Install valve using 4 screws. Do not over tighten.

Disclaimers

Like any other products we cannot be held liable for incorrect installation. Installation of performance enhancing products is solely at your own risk. Check your local emissions laws prior to installation. Except in cases of gross negligence the buyer holds us harmless.



Fuel Filter Housing Drain Valve removed (New Rings on top)



Fuel Drain Assembly view from Passenger side

For more information visit our website at: http://www.dfuser.com

http://www.dfuser.com Page 1 of 1