

Gauge Installation Guide Update (2003.25 – Up) 6.0L



2003+ 6.0L Powerstroke wire sources.

Red with yellow trace: switched ignition power (+12V). The 2 wires that get connected here are connected via a wire tap. The 2 wires are from the pyrometer and transmission temperature gauge amplifier boxes.



Instrument lighting power: Light Blue with Red tracer



The location of Transmission sender installed on a 6.0L 5R100.



Pyrometer (Exhaust Gas temperature)

Installation of the Exhaust Gas Temperature Gauge thermocouple (Pre-Turbo) on a 6.0L Powerstroke. Start with a small pilot hole and work your way up to 3/8" increasing 1 drill bit size at a time. This will cause all shavings to be small. Test the adapter provided, as you increase your bit size. The adapter shown installed above.