

Dfuser Steroid Power Module



“the bug that has no cure”

User Guide

What

This device is designed for 1999-2003 7.3L and 2003-up 6.0L F-250/F-350/F-450 and Excursion Powerstroke Turbo Diesel Engines as an easy and quick modification. Gain **+100HP and 180ft/lbs of torque!** over stock.

Installation Instructions

Pre-Cautions

- Take the time to read and understand these instructions.
- Use proper tools when installing
- Use proper safety gear
- On some vehicles the SES may flash for a second during heavy towing or hard acceleration. This is normal. A code may be stored in your PCM, and can be retrieved/cleared using the proper Diagnostics Tools. It is not normal for the SES light to remain on before or after this modification.
- This modification is considered a performance enhancement to your engine management system, and may alter emissions.

PS: For further information and questions please contact your distributor.

Tools recommended for installation

- 10mm socket, or wrench to ground wire
- Electrical Tape Used as protective covering on ICP connection
- Pliers to crimp the Red Scotchlok connector to the ICP line

Installation

Begin with removing the key from the ignition.

Ground Black Wire: Ground the unit with the open or ring terminal to the fire wall on the passenger side (**Figure 1**). If your module is designed to fit the cab, ground the wire under the dash. (**Figure 7**).

ICP Black Wire:

6.0L: On the 6.0L (03-early 04's) the ICP is behind the turbo up pipes. On the later 04 and up it is in the passenger side valve cover.

You will be able to access the ICP Sensor easily on the 6.0L (03-Early 04's). What you need to do is one of the following:

- Locate the center connector on your PCM (Computer Module) has the ICP signal wire going into it. It's the Dark Blue/Light Green and put provided Scotchlok™ (Red) Connectors to tap into it. The PCM is located on Driver's side, and the near battery. You need to remove the air filter apparatus to get to it.
- Another option is to tap into the same wire in the ¼ wire loom between the Radiator overfill tank and the Turbo housing (**Figure 12**).

7.3L: Locate the ICP (Ignition Control Pressure) sensor (**Figure 2**). The sensor is located on the top front driver's side of the engine valve cover by fuel filter) and it has three wires coming from it (**Figure 3**). Follow the wire loom connecting to the ICP sensor, find a convenient spot to tap into it, and separate the loom. Once the loom is spread apart locate the BL/LG (blue wire with a light green stripe) and tap into it using the supplied 3M Scotchlok™ (Red) T-Tap Disconnect Terminal.

98-Up: The ICP wire color is BL/LG (Blue with a Red Strip, but may vary)

Note: A quick connect pig-tail is available, at an additional cost, for all years except 2003.25-2004.5 6.0L. This pigtail can be used so no splicing is required into the ICP line. The Pig-tail will simply fit between the factory harness and ICP sensor.

MAP Sensor:

Locate the MAP sensor (Passenger side right above the HVAC assembly). Unplug the plug to it and insert the provided harness in between the factory plug and MAP sensor (**Figure 8**). 94-97 7.3L must be spliced in supplied 3M Scotchlok™ from left to right (Red, Green, and Black) (**Figure 6**)

Steroid Module:

Use the provided long zip ties to mount the module in a location close to the Passenger fender well.

Boost Tube:

Use the instruction for the Boost Tube when provided (Figure 5)

98-03: Available for the 7.3L Power Stroke Only.

Finishing Up:

Clean up your installation. Crank it up and test this new found horsepower! Start your testing with the dial in the full counter clockwise position. This is the minimal setting. As your vehicle warms up, add some power by moving the dial clockwise. 1/8 to ¼ turn should provide noticeable gains.

General Note

Some vehicles will not be able to use the full power of this module due to variance in the HPOP. Adjust your module accordingly. Start in the high setting, with dial wide open, and work your way down to insure your SES light does not come on. Once you determine the level where you SES light is not triggered, this should be your highest setting.

Parts List

Dfuser Steroid Power Module.

Scotchlok™ (Red) T-Tap Disconnect Terminal to ICP Harness

Installation Instructions provided via email or web link (print copy is available upon request)

Dfuser Boost Waste Gate Tube (Figure 6) – Only for 1999-2003 7.3L F-250/F-350 and Excursion

Disclaimers

Gauges are recommended. Due to the variances in stock engine and transmission programming, the Module can have varying results on Exhaust Gas Temperatures (EGT). For that reason we recommend the use of a pyrometer on your truck. If you choose to not install gauges prior to using your Module, do not use more than ¾ turn during heavy towing, and avoid spending more than 2-3 seconds at redline to avoid spiking EGT.

Remove all upgrades before servicing or prior to visiting the dealer. This avoids confusion from the dealer who may not be familiar with these products. These products can also interfere with the normal troubleshooting procedures that are used in fixing some common engine problems where injector timing and pressure are related.

Do not use this product until you have carefully read the following agreement.

This sets forth the terms and conditions for the use of this product. The installation of this product indicates that the BUYER has read and understands this agreement and accepts its terms and conditions

THIS IS A HIGH PERFORMANCE PRODUCT. USE AT YOUR OWN RISK.

Do not use this product until you have carefully read the following agreement.

This sets forth the terms and conditions for the use of this product. The installation of this product indicates that the BUYER has read and understands this agreement and accepts its terms and conditions

DISCLAIMER OF LIABILITY

Dfuser.com and its distributors, jobbers, and dealers (hereafter **SELLER**) shall in no way be responsible for the product's proper use and service. **THE BUYER HEREBY WAIVES ALL LIABILITY CLAIMS.**

The **BUYER** acknowledges that he/she is not relying on the **SELLER's** skill or judgment to select or furnish goods suitable for any particular purpose and that there are no liabilities which extend beyond the description on the face hereof and the **BUYER** hereby waives all remedies or liabilities, expressed or implied, arising by law or otherwise, (including without any obligations of the **SELLER** with respect to fitness, merchantability and consequential damages) or whether or not occasional by the **SELLER's** negligence.

The **BUYER** is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications and agrees to hold the **SELLER** harmless from any damage resulting from failure to adhere to such specifications.

The **SELLER** disclaims any warranty and expressly disclaims any liability for personal injury or damages. The **BUYER** acknowledges and agrees that the disclaimer of any liability for personal injury is a material term for this agreement and the **BUYER** agrees to indemnify the **SELLER** and to hold the **SELLER** harmless from any claim related to the item of the equipment purchased. Under no circumstances will the **SELLER** be liable for any damages or expenses by reason of use or sale of any such equipment.

The **BUYER** is responsible to obey all applicable federal, state, and local laws, statutes, and ordinances when operating his/her vehicle, and the **BUYER** agrees to hold **SELLER** harmless from any violation thereof.

The **SELLER** assumes no liability regarding the improper installation or misapplication of its products. It is the installer's responsibility to check for proper installation and if in doubt, contact the manufacturer.

The **SELLER** recommends that the **BUYER** temporarily remove this product from his/her vehicle when having the vehicle serviced by a dealership or other service facility. Failure to do so may cause erroneous diagnostic readings or misdiagnosis of vehicle problems. The **SELLER** assumes no liability for failure to do so.

LIMITATION OF WARRANTY

Dfuser.com (hereafter "**SELLER**") gives Limited Warranty as to description, quality, merchantability, fitness for any product's purpose, productiveness, or any other matter of **SELLER's** product sold herewith. The **SELLER** shall be in no way responsible for the product's open use and service and the **BUYER** hereby waives all rights other than those expressly written herein. This Warranty shall not be extended or varied except by a written instrument signed by **SELLER** and **BUYER**.

The Warranty is Limited to ninety (90) days from the date of sale and limited solely to the parts contained within the product's kit. All products that are in question of Warranty must be returned shipping prepaid to the **SELLER** and must be accompanied by a dated proof of purchase receipt. All Warranty claims are subject to approval by Dfuser.com.

Under no circumstances shall the **SELLER** be liable for any labor charged or travel time incurred in diagnosis for defects, removal, or reinstallation of this product, or any other contingent expenses.

Under no circumstances will the **SELLER** be liable for any damage or expenses insured by reason of the use or sale of any such equipment.

IN THE EVENT THAT THE BUYER DOES NOT AGREE WITH THIS AGREEMENT: THE BUYER MAY PROMPTLY RETURN THIS PRODUCT, IN A NEW AND UNUSED CONDITION, WITH A DATED PROOF OF PURCHASE, TO THE PLACE OF PURCHASE WITHIN TEN (10) DAYS FROM DATE OF PURCHASE FOR A FULL REFUND.

THE INSTALLATION OF THIS PRODUCT INDICATES THAT THE BUYER HAS READ AND UNDERSTANDS THIS AGREEMENT AND ACCEPTS ITS TERMS AND CONDITIONS.

AFTERMARKET PRODUCTS AND YOUR VEHICLE'S WARRANTY

Many of our customers ask, "Will your product void my vehicle manufacturer's warranty?" While the answer is straightforward from a legal standpoint, we also want to educate our customers (and aftermarket Consumers) on some industry realities and offer some common sense precautions to minimize your risk.


Consumers of aftermarket products are protected by The Federal Magnusson-Moss Warranty Act. The Act states that if something breaks on your car and you take it in for warranty repair, the dealer must honor your warranty unless they can prove that whatever modifications you have added to your car actually caused the problem.

While as a consumer, you have strong legal protection with regards to your vehicle's warranty, there is also a practical reality that different automotive manufacturers and dealers have greatly varying views on aftermarket products, in particular those that produce horsepower, such as performance enhancement chips, modified intake manifolds, or aftermarket exhaust systems. There are dealers and manufacturers out there that will use the presence of a horsepower upgrade to void your vehicle's warranty. They will do this regardless of whose product you are using. Any aftermarket company that does not acknowledge this is misleading you.

The bottom line is that while the law protects the consumer and provides for enforcement of the warranty, it is very difficult for most people to hire an attorney and fight a voided warranty. Dfuser.com recommends that you always disconnect and remove your module and monitor when you take your vehicle to a dealer for warranty work in order not to interfere with Diagnostic equipment.



Ground connection (Figure 1)



7.3L ICP (Figure 2)




ICP Splice on BL/GR wire (Figure 3)



Optional Boost Tube (Figure 5)



MAP Sensor location 94-97 (Figure 6)



Ground location under dash (Figure 7)




MAP Sensor 99-Up (Figure 8)



Optional Module Location (Figure 9)



ICP Sensor on Late 04-up (Figure 10)



Another View of ICP Sensor on Late 04-up (Figure 11)



Tap for 03-Early 04 (Figure 12)

Questions: Send email to Support@dfuser.com

dfuser.com
108 Evergreen Road
Georgetown, TX 78628-9500